

# **SODIUM ALCOHOLATES**

## Sodium t-Amylate (STA) in Toluene 25%

- a. 25 wt% Solution in Toluene
- b. Density at 25°C Approx 0.883 gm/ml

### 1. OTHER NAMES

- a. Sodium-tert-pentoxide in Toluene 25%
- b. Sodium-t-amylate in Toluene 25%
- c. Sodium-t-amoxide in Toluene 25%
- d. STA in Toluene 25%

### 2. CAS NO.

- a. 14593-46-5 for STA
- b. 108-88-3 for Toluene

## 3. FORMULA WEIGHT

110.13 gm/mole

## 4. TECHNICAL SPECIFICIATION

a. Appearance: Yellow liquid

b. Total alkalinity (%): 25-27

c. Hydroxide content (%): 1 max

d. STA content (%): 24-26

### 5. SOLUBILITY

STA is very soluble in toluene, cyclohexane, hexane, diglyme and tetrahydrofuran.

#### 6. STABILITY

Atmospheric moisture and carbon dioxide reacts readily with STA to produce Sodium hydroxide and Sodium carbonate. Tertiary amyl alcohol is liberated from these reactions. It develops yellow to brown colour solution after reacting with water. STA solution should be stored in a cool place away from heat, sparks and flame.

# 7. PACKAGING

- a. Sample packing from 100 gms to 500 gms in glass bottle
- b. 170 kgs in 210 lit. steel drum
- c. Any other packing as per customer request

**SUPARNA CHEMICALS LTD** 

54 A Mittal Tower, Nariman Point, Mumbai India.

Phone No: 022-22027446/7/8/9

Email Id: domesticsales@suparnachemicals.co.in export@suparnachemicals.co.in



# SODIUM ALCOHOLATES

## 8. SAMPLING INSTRUCTIONS

- a. The product is packed under dry nitrogen with positive pressure of nitrogen inside the drum.
- b. The quality of the product deteriorates very fast if exposed to atmosphere even for a brief period.
- c. While sampling, please ensure that the sample is taken out under dry nitrogen in a preweighed stoppered bottle and analysis is done immediately.
- d. After sampling, close the container securely after putting positive nitrogen pressure in the drum. This is very important so that the product does not deteriorate on storage.

### 9. SHIPPING INFORMATION

- a. UN-2920, PG 1
- b. Corrosive flammable liquid

## 10. PRODUCT PROPERTIES

- a. Very high purity
- b. Very strong base
- c. Low hydroxyl content
- d. Selective and specific in many organic reactions
- e. Stronger base than primary and secondary alcoholates
- f. Custom packaging available
- g. Any quantities in bulk

## 11. PRODUCT BENEFITS

- a. Strong hydrocarbon soluble base USED FOR:
- b. Deprotonations
- c. Base catalyzed reactions
- d. Elimination reactions
- e. Super base reaction with butyllithium
- f. Isomerization reaction

SUPARNA CHEMICALS LTD

54 A Mittal Tower, Nariman Point, Mumbai India.

Phone No: 022-22027446/7/8/9

Email Id: domesticsales@suparnachemicals.co.in export@suparnachemicals.co.in